

Installation Information

Item #P0035 and P0404 Leg Tub Shower Enclosure Unit

Warranted only if installed by a qualified licensed plumber. Use Teflon tape on all threaded connections.

Step 1: Installation of faucet -

1. Shut off the water supply to the fixture before installation.
2. Insert the faucet body inlet tubes through the 2 holes on the tub. Screw the lock nuts onto the threaded shanks and tighten to secure the faucet to your tub.
3. Attach the handles with the screws provided.

Step 2: Installation of Shower Riser, Diverter, Tub Filler and Enclosure and Shower Head

4. First slip the wall tee onto the shower riser about 10" below the crook in the riser. Only tighten slightly as later an adjustment will most likely be necessary. Set this piece aside for later.
5. Thread the short section of the riser into the bottom of the tub filler and tighten.
6. Thread the middle section of the riser into the top of the tub filler. Use of Teflon tape will aid in aligning all pieces. Do not completely tighten.
7. Thread the shower control valve onto the top of the middle section of the riser. Use Teflon tape. Do not completely tighten.
8. Thread the top section of the riser into the top of the shower valve using Teflon tape. **NOTE: IF USING WITH AN ENCLOSURE, MAKE SURE YOU HAVE ALREADY SLIPPED THE WALL TEE ONTO THE TOP SECTION.**
9. All connections can now be tightened and aligned.
10. Put the riser nut and cone washer onto the end of the riser leaving about ¼" of riser showing at the riser end.
11. Install the riser onto the faucet, making sure that the riser is fully inserted into the female portion of the faucet and thread on the nut to the faucet connection compressing the cone washer.
12. **Please note:**
Many leg tubs are slightly slanted on the end. The enclosed riser nut and large cone washer have been designed to compensate for this fact. It is important to only hand tighten the riser to the faucet, then make the riser vertical using the wall and ceiling braces, and finally tighten the riser nut.
13. **Enclosure Instructions:**
14. **Two people are needed for the remaining steps.** Take one of the halves of the shower ring and slip it onto the wall tee. Be certain that the threaded hole is towards the outside of the ring. Insert screws and tighten.
15. Take the ceiling tee and slip the free ends of the shower ring over this part. Be certain that the threaded hole is towards the top of the ring.
16. After measuring the proper length that the wall and ceiling braces need to be, cut these pieces off at the unthreaded end to the desired length. **DO NOT TAKE THE THREADED PORTIONS OF THE BRACES INTO ACCOUNT WHEN MEASURING THE BRACES.**
17. Install the escutcheons onto the wall and ceiling in their proper positions.
18. Very carefully screw ceiling braces firmly into the ceiling tee. Take care not to flex this joint a great deal. As you then install the ceiling braces into the ceiling escutcheon and tighten the screw, someone must hold steadily the other end of the shower ring to reduce flex.
19. Very carefully screw the wall brace firmly into the wall tee and do not allow the joint to flex. You may now adjust the wall tee to the desired height on the riser. Install the wall brace into the wall escutcheon and tighten the screw.
20. Thread on your shower head to the riser using Teflon tape on threads.