

Installation Information

Item #P0872

Warranted only if installed by a qualified licensed plumber. Use Teflon tape on all threaded connections.

When being used on an exposed shower system:

1. Connect the bottom of the center diverter valve to a $\frac{3}{4}$ " male outlet on the faucet body.
2. Connect your shower riser, shower head and other accessories. (sold separately)
3. Connect each valve/spray head unit at the union on side of the diverter valve. (we recommend doing this step last to avoid these pieces invading the work area)

